

NEXT


ABEL MOD SF DIN RUST - W46742

Actual product size

Single Chair X3: (H)70X(W)66X(D)71CM

3-Seat Sofa X1: (H)70X(W)228X(D)71CM

Table X1: (H)68/44X(W)145X(D)74.5CM



Item number	Fabric name-Leg	Fabric composition
W46742	Rust - Natural Frame	100% Polyester

IMPORTANT-RETAIN FOR FUTURE REFERENCE

Need Help?

With: A ssembly instr uctions
Missing or da maged parts


CALL: 0333 777 8999

BEFORE YOU START

Number of people required to assemble
Two people are required to assemble this item
Time to assemble : 45 minutes

ABEL MOD SF DIN RUST - W46742

Assembly instructions



Item number	Product Description	Component	Fabric composition
W46742	Abel Mod Sf Din Rust	Cover fabric	100% Polyester

Warnings

This product is for domestic and outdoor use only.
We suggest you retain these instructions for future reference.
Keep fittings out of children's reach. Keep children away when constructing your furniture.
This product should only be used on firm level ground.
Do not sit on the table.
Do not jump or stand on the product.

Do's

Do spend a short time reading through this leaflet before you start.
When you are ready to start, make sure that you have the right tools and plenty of space. Due to the size of the product we recommend that it is assembled in the location intended for final use.
Unwrap all packaging materials and place the components on a clean surface to protect it from damage. We recommend that the packaging is used to protect any fabrics and surfaces during assembly. Before beginning assembly carefully check that you have all the parts and fixings.
Ensure the product is fully assembled as illustrated and all fixings are fully tightened before use.
Please retain the assembly tools. You will need them in the future to re-tighten the bolts, or if you want to dismantle the furniture for storage.
Please make sure that the product is clean and dry before putting it into storage.

Do not

Do not position your product close to sources of intense heat, such as barbecues or patio heaters.
Do not sit on arms or the back of seating which may cause distortion or damage the frame.
Do not wash covers in a washing machine.
Do not use a jet or pressure washer to clean your furniture.
Avoid allowing pets on upholstered products as their claws may cause damage to the leather or fabric.

Care & Maintenance

Check fixings regularly to ensure they remain tight.
Lift the assembled product when moving it; do not drag it as this can cause damage.
The frame of this product is suitable for all year outdoor use. It is however still recommended to cover products when not in use for long periods to keep it clean.
Cushions are resistant to light summer showers, the water resistant covers will prevent the fillings from getting wet. However in heavy showers or long periods of wet weather they should be taken indoors or stored in a shed, garage or cushion box.
Take cushions in at night or when it's raining as the dampness will cause mould to grow.
Fabrics have been tested for outdoor suitability; even so, please be aware that, over time, fabrics may fade a little after exposure to direct sunlight for long periods.
Regularly plump cushions to maintain their shape.

Need Help?

With: A ssembly instr uctions
Missing or da maged parts

CALL: 0333 777 8999

Cleaning

Frame

Wipe occasionally with a soft damp cloth.

Then dry with a clean soft cloth.

Use water and a mild detergent.

Don't use harsh chemicals as this may cause discolouration of the material/finish.

Remove algae from woven materials using a brush and soapy water by scrubbing gently and rinsing with clean water.

Cushions & Upholstered surfaces

Regularly clean with a vacuum cleaner or lightly brush with a soft bristled brush.

Covers should be cleaned with a damp soapy cloth or sponge.

Soak up any spillages quickly by blotting with a clean, dry absorbent cloth.

Any remaining stains should be removed with using water, but stubborn stains may need a mild household detergent.

Solid spillages should be removed with a teaspoon or flat utensil, before following the instructions for spillages.

Repeat until the stain is removed and allow to air dry.

Clean cushions in situ only.

Do not remove cushion covers to clean.

DO NOT WASH.

Clean all parts of the product at the same time.

For stubborn stains contact a professional cleaner.

Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on **0333 777 8999** and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product please contact our customer service team on **0333 777 8999**. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services
Next Retail Ltd,
Desford Road,
Leicester,
LE19 4AT


To View our full furniture range
please visit www.next.co.uk

Need Help?

With: Assembly instructions
Missing or damaged parts


CALL: 0333 777 8999



GETTING TO KNOW YOUR PRODUCT



X3

Components supplied. Please use this guide if you require replacement parts.


Ref	Visual	Qty	Ctn
1		3	1
2	 <p>(W)66X(D)70X(H)11CM</p>	3	1

Ref	Visual	Qty	Ctn
7	 <p>(W)68X(D)44X(H)22CM</p>	3	1
8		12	1


NEXT ABEL MOD SF DIN RUST

W46742 Assembly instructions

1




2




NEXT ABEL MOD SF DIN RUST


W46742 Assembly instructions

GETTING TO KNOW YOUR PRODUCT




Components supplied. Please use this guide if you require replacement parts.

Ref	Visual	Qty	Ctn
3	 (W)60X(D)44X(H)22CM	3	1
4		1	1
5		1	1

Ref	Visual	Qty	Ctn
6	 (W)223X(D)70X(H)11CM	1	1
7	 (W)68X(D)44X(H)22CM	2	1
8		4	1

**Fixtures and fittings supplied
(actual size)**



Ref	Dimensions	Qty	Spare Qty
A	M6X20MM	2	1
B	Ø14	2	1



**Fixtures and fittings supplied
(not to scale)**


Ref	Qty	Spare Qty	Visual
C	1	1	

1



A	 M6X20MM	2
B		2
C		1


2



NEXT ABEL MOD SF DIN RUST

W46742 Assembly instructions


3





NEXT ABEL MOD SF DIN RUST

W46742 Assembly instructions



GETTING TO KNOW YOUR PRODUCT



1




2




NEXT ABEL MOD SF DIN RUST

W46742 Assembly instructions


1



2



3



NEXT

ABEL MOD SF DIN RUST - W46742

Assembly instructions

ABEL MOD SF DIN RUST - W46742

Actual product size

Single Chair X3: (H)70X(W)66X(D)71CM

3-Seat Sofa X1: (H)70X(W)228X(D)71CM

Table X1: (H)68/44X(W)145X(D)74.5CM

