



SWOON

ZIGGY TV CABINET



1 x Box



2 x Leg



12 x Allen bolt 6 x 16 mm



12 x Washer 8 x 16 mm



16 x Shelf Pin



1 x Allen Key 4 mm

EXTRA 2 x Allen bolt 6 x 16 mm
 HARDWARE 2 x Washer 8 x 16 mm
 2 x Shelf Pin

" Important "

Use mat or carpet to assemble the product to avoid scratches.

