Item Identifiers	
Brand	Katie Loxton
Item Number	AK2800
Article Number	Not Applicable
EAN	5056625423132
Legal Online Product Information	
Function	Candle
Specific Product Information	Home Sentiment Candle
Net Weight / Volume	Not Applicable
Instructions for safe use	Never leave a burning candle unattended. Burn candle out of reach of children and pets. Always leave at least 10 cm between candles. Do not burn candles on or near anything that can catch fire. Trim wick to about 1 cm before lighting. Do not place candles near a source of heat. Harmful to aquatic life with long lasting effects If medical advice is needed, have product container or label at hand. Keep out of reach of children. Avoid release to the environment. Dispose of contents/container to hazardous or special waste collection point, in accordance with local, regional, national and/or international regulation. Approximate burn time 25 – 30 hours. To ensure the wax burns evenly, burn for a minimum of 2 hours and a maximum of 4 hours. Extinguish flame when there is 1cm of wax left and do not relight.
Product Expiry	Check product for expiry date
Ingredients Information	
Ingredients	Citronellol, Benzoic acid, 2-hydroxy-, hexyl ester, Octanal, 2-(phenylmethylene), Coumarin
VOC Level	Not Applicable
Alcohol Content	Not Applicable
Warning and Hazard Information	
Warning Pictograms	
Hazard and Precautionary Statements	Never leave a burning candle unattended. Burn candle out of reach of children and pets. Always leave at least 10 cm between candles. Do not burn candles on or near anything that can catch fire. Trim wick to about 1 cm before lighting. Do not place candles near a source of heat. Harmful to aquatic life with long lasting effects If medical advice is needed, have product container or label at

	hand. Keep out of reach of children. Avoid release to the environment. Dispose of contents/container to hazardous or special waste collection point, in accordance with local, regional, national and/or international regulation. Approximate burn time 25 – 30 hours. To ensure the wax burns evenly, burn for a minimum of 2 hours and a maximum of 4 hours. Extinguish flame when there is 1cm of wax left and do not relight.
EU Authorised Representative Address	Cherwell Business Village, Unit F168, Southam Rd, Banbury OX16 2SP
UFI Code	Not Applicable