


N46493
AE0047
Nordic Cedar
Candle 280g

Front Page



CARE & USE

Ensure melt pool reaches the side of vessel on the first burn.
Always trim the wick to 10mm before re-lighting.
Clear any debris before each lighting.
Keep out of draughts and direct sunlight.

Caution: Burn within sight and never leave a burning candle unattended.
The vessel may become hot during use. Never move a hot burning candle.
Extinguish when 10mm of wax remains and do not re-light with a low wax level.

When finished clean out and up-cycle vessel into a plant pot.



HINGE / SPINE

----- Print Safe Area (does not print)


_____ Cutter only (does not print)

Label size: 50mm dia.



Inside Front
Page



Page 3



Page 4



Base

