




ode



Batteries required: 2 x AAA batteries per candle, included. This product is battery operated with the battery compartment located at the base of the candle, they are non-replaceable.

Battery Warning. Disposal of batteries should be done correctly. Do not dispose of batteries in domestic waste. Your local authority has made special arrangements for the disposal of used batteries; contact them for further details. Do not attempt to recharge non-rechargeable batteries. Remove rechargeable batteries from the product before recharging. The supply terminals are not to be short-circuited. Do not place in a warm position such as direct sunlight or on a television top. Do not place on an unprotected surface. Do not light.
Keep out of reach of children.