Product size:

H70 x W36.6 x D28.2 cm

Need Help?

With: Assembly instructions
Missing or damaged parts

IMPORTANT ─ RETAIN FOR FUTURE REFERENCE

CALL: 0333 777 8999

next

CADDY WIDE SAGE
AA8224
Assembly instructions

GETTING TO KNOW YOUR PRODUCT

Ax1

Cx1   Bx2

Ex1

Dx1   Fx2

1

Cx1

Bx2

Ax1

Combine the frame A, B and C until the spring pin comes through the hole.

2

Dx1

Push the back panel D into the frame from front to back.

3

Ex1

Set the height of E as you like and lock part E into the frame correctly.

4

Fix the caddy to the wall with component F and fixings appropriate for your wall type (not included).

5

All steps completed.