BEFORE YOU GET STARTED...

We're confident you'll love your gorgeous new Next furniture. However, it's worth making absolutely certain before you put it all together.

So, let's quickly run through these three steps:

1. COLOUR

Make sure you're happy with the colour No need to unpack everything, just check the first component.

2. PROTECTIVE PACKAGING

If you're happy, then it's time to get opening! Start by laying everything out on the protective packaging – this will prevent anything getting scratched.

3. PARTS PAGE

Finally, double check you have all the pieces by referencing the parts page of the instructions.

TIPS FOR RETURNS

Not completely happy with the product? No problem.
We just need everything back in the original packaging, so follow the steps below and this will ensure a super-smooth returns process and no delay to your refund.



- Check everything is there (the 'parts tage' is a handy checklist).
- Pop all the loose fittings and fixtures into the packaging provided or tie them up in a plastic bag.
- Wrap all the big components back up in the original protective packaging.
- Close up the box and seal it securely (don't be afraid to use plenty of tape).

DON'T




- Leave anything assembled all components should be an antied and separately packed.
- Put loose fixtures and fittings straight into the box.
- Throw it back in the box arelessly as it may get damaged.



Assembly instructions

Actual product size H955 x W2010 x D970 mm



Need Help?

With: Assembly instructions Missing or damaged parts

CALL:0333 777 8999

IMPORTANT - KEEP FOR FUTURE REFERENCE

BEFORE YOU START

Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from construction area.

This product should only by used on firm, level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

WARNING: Do not place this child's bed near heat sources, windows and other furniture.

WARNING: Do not use this child's bed if any part is broken, torn or missing.

WARNING: Assembly by adult only.

WARNING: All assembly fittings should always be tightened

properly and checked periodically.

WARNING: Not suitable for children under 4 years.

WARNING: Once assembled this bed is not designed to be disassembled and reassembled. Children are likely to play, bounce, jump and climb on beds, therefore the child's bed should not be placed too close to other furniture or windows, blind cords, curtain pulls or other strings or cords and should be placed either tight to any wall or have a gap of 300mm between the wall and the side if the bed. The size of the mattress to be used with the child's bed is 900mm x 1900mm.

This bed conforms to BS 8509:2008 + A1:2011

Don'ts

Do not tighten screws until fully assembled.

Do not over tighten screws or bolts.

Do not drag or pull your furniture.

Do not use this product if parts are missing, damaged or worn.

Never use scourers, abrasives or chemical cleaners.

Number of people required to assemble

Two people are required to assemble this item



Time to assemble



30 minutes

Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools, plenty of space.

Due to the size of this product we recommend that it is assembled in the room intended for use.

Unwrap all packaging materials and place the components on a clean surface to protect them from damage.

We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Ensure the product is fully assembled as illustrated and all fixings are fully tightened before use. Check fixings regularly to ensure they remain tight.

When moving your assembled bed. Lift the bed and never to drag it.

Never allow any kind of liquid to remain on your furniture. Absorption can cause materials to warp or finishes to de-laminate.

To clean your item, please use a vacuum or lightly brush clean.

Missing parts

If you are missing any fixtures and fittings for your product please contact our customer service team on **0333 777 8999** and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product please contact our customer service team on **0333 777 8999**. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

You can write to us at


Home Customer Services Next Retail Ltd, Desford Road, Leicester, LE19 4AT,

To view our full furniture range please visit www.next.co.uk



511731

Assembly instructions



Components supplied - Use this guide if you require a replacement part.

Ref	Dimensions	Visual	Qty
1	955*970*50		1
2	955*970*50		1
3	1930*705*20		1
4	1920*110*45		1
5	918*62*9*15 PCS		1

Ref	Dimensions	Visual	Qty
6	915*50*25		2



511731


Assembly instructions

Ref	Dim en sions	Qty	Spare
A	M 6x20m m	16	1
В	4 m m	1	1
С	Ø 6*16	16	1
D	Ø 6*18	12	1
Е	6x25m m	6	1

mm 10 20 3	0 40 50	60 70	80 90	100 110

511731


Assembly instructions






Assembly instructions

3







Assembly instructions

Actual product size H955 x W2010 x D970 mm Inner size L1920 x D920 mm

