

**BT-2650**

**FOLDABLE TREADMILL**



SINCE 1965

## USER'S MANUAL




<http://www.body--sculpture.com>

# Important Safety Information

**Please keep this manual in a safe place for easy reference.**


1. It is important to read this entire manual before assembling and using the equipment. Safe and effective use can only be achieved if the equipment is assembled, maintained and used properly. It is your responsibility to ensure that all users of the equipment are informed of all warnings and precautions.
2. Before starting any exercise program you should consult your doctor to determine if you have any medical or physical conditions that could put your health and safety at risk, or prevent you from using the equipment properly. Your doctor's advice is essential if you are taking medication that affects your heart rate, blood pressure or cholesterol level.
3. Be aware of your body's signals. Incorrect or excessive exercise can damage your health. Stop exercising if you experience any of the following symptoms: pain, tightness in your chest, irregular heartbeat, extreme shortness of breath, lightheadedness, dizziness or feelings of nausea. If you do experience any of these conditions you should consult your doctor before continuing with your exercise program.
4. Keep children and pets away from the equipment. The equipment is designed for adult use only.
5. Use the equipment on a solid, flat level surface with a protective cover for your floor or carpet. To ensure safety, the equipment should have at least 0.5 meters of free space all around it.
6. Before using the equipment, check that the nuts and bolts are securely tightened.
7. The safety of the equipment can only be maintained if it is regularly examined for damage and/or wear and tear.
8. Always use the equipment as indicated. If you find any defective components while assembling or checking the equipment, or if you hear any unusual noises coming from the equipment during use, stop immediately. Do not use the equipment until the problem has been rectified.
9. Wear suitable clothing while using the equipment. Avoid wearing loose clothing that may get caught in the equipment or that may restrict or prevent movement.
10. The equipment has been tested and certified to EN957 under class H.C. Suitable for home use only. Maximum weight of user: 100kg. Braking ability is independent of speed.
11. The equipment is not suitable for therapeutic use.
12. Care must be taken when lifting or moving the equipment so as not to injure your back. Always use proper lifting techniques and/or seek assistance if necessary.

# EXPLODED-VIEW ASSEMBLY DRAWING




# PART LIST

NO.	DESCRIPTION	QTY	NO.	DESCRIPTION	QTY
1	MAIN FRAME	1	33	LEFT SIDE HANDLE POST	1
2	REAR ROLLER	1	34	PULSE SENSOR	2
3	PLASTIC WASHER	4	35	RUNNING BOARD	1
4	STEEL END	2	36	RUNNING WASHER	1
5	BOLT M6	2	38	COVER	1
6	REAR END CAP(L/R)	2	39	FRONT AXLE	1
8	REAR AXLE	1	40	FRONT ROLLER	1
9	END CAP	2	43	HANDLEBAR GRIP	2
10	SIDE RAIL	2	44	COMPUTER MOUNT BRACKET	1
11	T TYPE PLUG	2	46	BOLT M4*10	4
19	NUT M8	2	47	BOLT M5*10	2
20	BOLT M8*40	2	A	BOLT M8*50	4
21	PLASTIC WHEEL	2	B	WASHER Φ8	4
23	BOTTOM FRAME	1	C	BOLT M5*10	2
24	RIGHT SIDE HANDLE POST	1	D	NUT M8	4
26	PULSE SENSOR WIRE	2	F	BOLT M8*50	2
27	COVER OF HANDLE(R)	1	G	WASHER Φ8	2
28	COVER OF HANDLE(L)	1	H	BOLT M8*45	4
29	HANDLEBAR	1	I	BOLT M4	4
30	COMPUTER	1	J	KNOB M8	1
31	COMPUTER SENSOR WIRE	1SET	K	WRENCH	1
32	BOLT M5*25	8	N	WRENCH S5	1



PART LIST					
NO.	DESCRIPTION	QTY	NO.	DESCRIPTION	QTY
<b>1</b>	MAIN FRAME	1	<b>29</b>	HANDLEBAR	1
<b>23</b>	BOTTOM FRAME	1	<b>30</b>	COMPUTER	1
<b>24</b>	RIGHT SIDE HANDLE POST	1	<b>33</b>	LEFT SIDE HANDLE POST	1
<b>27</b>	COVER OF HANDLE(R)	1	<b>38</b>	COVER	1
<b>28</b>	COVER OF HANDLE(L)	1	<b>44</b>	COMPUTER MOUNT BRACKET	1

**Notice**

Read this manual before assembly

Recognize the spare parts first

Check the hardware













Ensure that you have the right tools

Prepare an area to assemble


Follow the instruction accordingly

Never force the joints

Periodically tighten the joints

	# A	M8*50	4PCS
	# F	M8*50	2PCS
	# H	M8*45	4PCS
	# C	M5*10	2PCS
	# I	M4	4PCS
	# 46	M4*10	4PCS
	# B	φ8	4PCS
	# G	φ8	2PCS
	# D	M8	4PCS
	# J	M8	1PCS
	# K		1PCS
	# N	S5	1PCS


# ASSEMBLY INSTRUCTION



## STEP 1


Open the carton, get the above parts out and put the bottom frame (23) on the level ground. Attach right side handle post (24) and left side handle post (33) onto bottom frame (23) and fasten with M8\*50 bolts (A), washers (B) and M8 nuts (D).






## **STEP 2**

Attach cover (38) onto main frame (1) and fasten with M4\*10 bolts (46) .




### **STEP 3**

Fasten right side handle post (24) and left side handle post (33) onto main frame (1) with M8\*50 bolts (F) and washers (G).




#### **STEP 4**

Connect computer sensor wires (31) together Attach handlebar (29) onto handle posts, and fasten with M8\*45 bolts (H).




## **STEP 5**

Attach covers of handle L,R (28) onto handlebar and fasten with M4 bolt (I) Attach computer mount bracket (44) onto handlebar and fasten with M5\*10 bolt (C).



## **STEP 6**

Connect computer sensor wires (31) ( 26 ) . Attach computer (30) onto computer mount bracket (44) and fasten with M5\*10 bolts (47).





## **STEP 7**

---

Insert M8 knob (J) to secure the platform.

# FOLDING INSTRUCTION

Please loosen knob(J) completely before folding the treadmill. Then lift the NO.1 Main frame to the upright position and use knob(J) to fasten it tightly to prevent any accident in advance




## EXERCISE INSTRUCTIONS

Using your TREADMILL will provide you with several benefits, it will improve your physical fitness, tone muscle and in conjunction with a calorie controlled diet help you lose weight.


### 1.The Warm Up Phase

This stage helps get the blood flowing around the body and the muscles working properly. It will also reduce the risk of cramp and muscle injury. It is advisable to do a few stretching exercises as shown below. Each stretch should be held for approximately 30 seconds, do not force or jerk your muscles into a stretch - if it hurts, STOP.



### 2.The Exercise Phase

This is the stage where you put the effort in. After regular use, the muscles in your legs will become more flexible. Work to your own pace but it is very important to maintain a steady tempo throughout. The rate of work should be sufficient to raise your heart beat into the target zone shown on the graph below.



This stage should last for a minimum of 12 minutes though most people start at about 15-20 minutes



### **3. The Cool Down Phase**

This stage is to let your Cardio-vascular System and muscles wind down. This is a repeat of the warm up exercise e.g. reduce your tempo, continue for approximately 5 minutes. The stretching exercises should now be repeated, again remembering not to force or jerk your muscles into the stretch.

As you get fitter you may need to train longer and harder. It is advisable to train at least three times a week, and if possible space your workouts evenly throughout the week.

### **MUSCLE TONING**

To tone muscle while on your TREADMILL, you will need to have the resistance set quite high. This will put more strain on your leg muscles and may mean you cannot train for as long as you would like. If you are also trying to improve your fitness you need to alter your training program. You should train as normal during the warm up and cool down phases, but towards the end of the exercise phase you should increase resistance making your legs work harder. You will have to reduce your speed to keep your heart rate in the target zone.

### **WEIGHT LOSS**

The important factor here is the amount of effort you put in. The harder and longer you work the more calories you will burn. Effectively this is the same as if you were training to improve your fitness, the difference is the goal.

# CONSOLE INSTRUCTIONS



## SPECIFICATIONS: NO SMS\_203

TIME.....00:00-99:59  
SPEED(SPD).....0-99.9KM/H(ML/H)  
DISTANCE.....0-99.99KM(ML)  
CALORIES.....0-999.9KCAL  
※ODOMETER(ODO).....0-999.9KM(ML)  
※PULSE(PUL).....40~240BPM

## KEY FUNCTIONS:

**MODE:** This key lets you to select and lock on to a particular function you want.

**SET:** Can to proceed the data establish for “TIME” “DISTANCE” “CALORIES”

**RESET:** The key to reset the value to zero by pressing the key

## OPERATION PROCEDURE:

### 1. AUTO ON/OFF

The system turns on when any key is pressed or when it sensor an input from the speed sensor.  
The system turns off automatically when the speed has no signal input or no key are pressed for approximately 4 minutes

### 2. RESET

The unit can be reset by either changing battery or pressing the MODE key for 3 seconds.

### 3. MODE

To choose the SCAN or LOCK if you do not want the scan mode, press the MODE key when the pointer on the function you want which begins blinking.

## **FUNCTIONS:**

### **1. TIME:**

Press the MODE key until pointer lock on to TIME. The total working time will be shown when starting exercise.

### **2. SPEED:**

Press the MODE key until the pointer advance to speed. The current speed will be shown.

### **3. DISTANCE:**

Press the MODE key until the pointer advance to DISTANCE. The distance of each workout will be displayed.

### **4. CALORIE:**

Press the MODE key until pointer lock on CALORIE. The calorie burned will be displayed when starting exercise.

### **5. ODOMETER (Option):**

Press the MODE key until the pointer advanced to ODOMETER. The total accumulated distance will be shown.

### **6. PULSE (Option):** Press the MODE key until the pointer advance to PULSE. User's current heart rate will be displayed in beats per minute. Place the palms of your hands on both of the contact pads(or put car-clip to ear). And wait for 30 seconds for the most accurate reading.

**SCAN:** Automatically display changes every 4 seconds.

**BATTERY:** If improper display on monitor, please reinstall the batteries to have a good result



S I N C E 1 9 6 5

COPYRIGHT©2012 BY HI MARK INTERNATIONAL LTD.  
ALL RIGHTS RESERVED.UNAUTHORIZED DUPLICATION IS A VIOLATION OF LAW