


M90418

Assembly instructions

Actual product size

H98 x W119 x D33cm



Need Help?

With: Assembly instructions
Missing or damages parts

CALL: 0333 777 8999

IMPORTANT - RETAIN FOR FUTURE REFERENCE



M90418

Assembly instructions

BEFORE YOU START

Number of people required to assemble

Two people are required to assemble this item



Time to assemble



Tools required



not supplied

Do's

We suggest you spend a short time reading through this leaflet before you start

When you are ready to start, make sure that you have the right tools and plenty of space

Unwrap all packaging materials and place the components on a clean surface to protect it from damage, we recommend that the packaging is used to protect the surfaces during assembly

Carefully check that you have all the parts before beginning assembly

Due to the size of the product we recommend that it is assembled in the room intended for use

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use

Wipe occasionally with a soft cloth slightly dampened with water. Then buff with a dry clean soft cloth

Wood will mellow and change colour over time, we recommend that ornamenta and itema placed on the surface are moved regularly for the first few months to prevent uneven mellowing

Don'ts

Do not drag or pull your furniture

Do not rub or scrub the surface when cleaning

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish


Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate

Do not place hot items (e.g.hot drinks) directly on to the wood surface. Please make sure you use a placemat or coaster



M90418 Assembly instructions

GETTING TO KNOW YOUR PRODUCT





M90418

Assembly instructions

Components supplied. Please use this guide if you require replacement parts.

Ref	Dimensions	Visual	Qty	Ctn
1	115 x 22cm		1	1
2	119 x 33cm		1	1
3	75.2 x 16cm		1	1
4	75.2 x 16cm		1	1
5	78 x 7.7cm		1	1
6	78 x 7.7cm		1	1
7	68.5 x 12.8cm		1	1
8	68.5 x 12.8cm		1	1
9	75.2 x 7.8cm		1	1
10	75.2 x 7.8cm		1	1
11	18.5 x 12.4cm	S	1	1

Ref	Dimensions	Visual	Qty	Ctn
12	18.5 x 12.4cm		1	1
13	91.1 x 7.8cm		1	1
14	91.1 x 7.8cm		1	1
15	72.3 x 12.8cm		1	1
16	78 x 10cm		1	1
17	78 x 10cm		1	1
18	87.6 x 10cm		1	1
19	70.3 x 72.2cm		1	1




M90418

Assembly instructions

Fixtures and fittings supplied (actual size)

supplied (actual size)					
Ref	Dimensions	Qty	Spare Qty		
а	Ø5 x 50mm	23	2		
b	Ø4 x 25mm	13	2		
С	Ø8 x 38mm	N/A	2		
d	Ø8 x 40mm	N/A	1		
d1	Ø8 x 30mm	N/A	2		
f	Ø15 x 12mm	N/A	2		



Fixtures and fittings supplied (not to scale)


Ref	Dimensions	Qty	Spare Qty	Visual
o	N/A	2	N/A	




M90418

Assembly instructions


TITUS TIGHTENING INSTRUCTIONS




Line up the arrow on the CAM with the PIN.




Push the pins into the holes in the panel to be joined.



Make sure there is no gap between the panels.




Use a cross-point screwdriver (PH2 or PZ2 is ideal) to tighten the cams and lock the panels together.




The panels are locked when each cam is turned to between 1/2 and 2/3 of a full turn (Maximum rotation)

TOWNHOUSE COMPACT FIRE SURROUND M90418



TOWNHOUSE COMPACT FIRE SURROUND

M90418




TOWNHOUSE COMPACT FIRE SURROUND

M90418


TOWNHOUSE COMPACT FIRE SURROUND

M90418 Assembly instructions






M90418






M90418





Assembly instructions




The hole need to be drilled 1049mm apart

Mark where the holes need to be drilled.

Use a spirit level to check that the fixings are level.




12



Warning:Always ensure intended wall area to be drilled is free from hidden electrical wires, water and gas pipes.




13




Insert an appropriate wall plug into each hole. Insert the screws and tighten, leaving the screw head axposed by 1/4 inch (6mm)

14





M90418



Warnings

We suggest you retain these instructions for future reference.

Keep fittings out of children's reach and keep children well away from construction area.

This product should only be used on firm level ground.

Please periodically check all fittings and re-tighten as necessary.

Please do not sit or stand on your furniture.

Avoid exposing the furniture to excessive heat or direct sunlight as this can cause deterioration of the colour.

Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to protect it from damage

Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Home service technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999. If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible. If you have had the product for more than 28 days we will send an independant home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Service Next Retail Ltd. Desford Road, Leicester, LE19 4AT

To view our full furniture range please visit www.next.co.uk