

NEXT

CROSBY STORAGE MODULAR SOFA

Assembly instructions





Actual product size

Corner piece:H86xW95xD95CM

Centre piece:H86xW77xD95CM

Footstool piece:H47.5xW77xD77CM

Double Footstool:H47.5xW155xD77. 5CM



SOLD SEPARATELY

PART	Item number	Fabric name	Fabric composition
Corner piece	AY5861	Brushed Weave Olive Green	100% polyester
	AU6820	Brushed Weave Oyster	100% polyester
	F30482	Soft Velvet Rust	100% polyester
Centre piece	AY5860	Brushed Weave Olive Green	100% polyester
	AU6821	Brushed Weave Oyster	100% polyester
	F30480	Soft Velvet Rust	100% polyester
Footstool	AY5862	Brushed Weave Olive Green	100% polyester
	AU6822	Brushed Weave Oyster	100% polyester
	F30483	Soft Velvet Rust	100% polyester
Double Footstool	F98517	Brushed Weave Olive Green	100% polyester
	H34932	Brushed Weave Oyster	100% polyester
	H34933	Soft Velvet Rust	100% polyester

IMPORTANT RETAIN FOR FUTURE REFERENCE

Need Help?

With: Assembly instructions
Missing or damaged parts

CALL: 0333 777 8999


BEFORE YOU START

CROSBY STORAGE MODULAR SOFA Assembly instructions

Number of people required to assemble

Two people are required to assemble this item

Time to assemble: 15 minutes



Do's

We suggest you spend a short time reading through this leaflet before you start.

When you are ready to start, make sure that you have the right tools and plenty of space.

Unwrap all packaging materials and place the components on a clean surface to protect it from damage. We recommend that the packaging is used to protect the surfaces during assembly.

Carefully check that you have all the parts before beginning assembly.

Ensure the product is fully assembled as illustrated and all fixings fully tightened before use.

Check fixings regularly to ensure they remain tight.

Always wipe dry after cleaning.

For fabric sofas, our fixed cover fabric sofas can be cleaned by using water and a neutral soap to remove stains. Always test the treatment on a concealed area first. For loose cover please reference the care label inside the cover for guidance.

For PU sofas, please lightly brush clean or lightly wipe with a slightly dampened cloth. Keep away from strong heat sources. Occasional overall cleaning should be carried out approximately once a month by using a slightly damp-ened soft cloth. Then buff with a dry clean soft cloth.

For upholstery with removable seating cushions, to ensure your sofa continues to look great, it is important to regularly: Plump cushions to prevent creasing, attenuing and distortion of the cushion border. Turn reversible cushions to ensure even wear. Swap the left and right cushions to balance out wear to the covers and fillings. Please note your foam cushions will soften slightly within the first few weeks of use. This will not affect their durability.

Don'ts

Never allow any kind of liquid to remain on your furniture.

Absorption can cause wood to warp or finishes to delaminate.

Do not use silicone based furniture polish.

Silicone in furniture polishes can break down the lacquer finish.

Missing parts

If you are missing any fixtures and fittings for your product. Please contact our customer service team on 0333 777 8999 and they will be happy to arrange for a replacement to be sent to you free of charge.

Warnings

We suggest you retain these instructions for future reference. Keep fittings out of children's reach and keep children well away from construction area.

Please periodically check all fittings and re-tighten as necessary.

Upholstered furniture should not be exposed to direct sunlight for long periods.

Please do not place your upholstery in direct contact with a strong heat source.

Leave a 30 cm gap between upholstery and radiators.

Please do not allow children to jump up and down on the upholstery.

Avoid allowing pets on the upholstery as their claws may cause damage to the leather/fabric.

Avoid sitting on the arms of the upholstery or on the front edge of the seat as this can compress the foam and damage the frame of your upholstery causing premature wear and distortion.

When your new sofa arrives, you may notice that some of the cushions may have been creased or squashed during transit.

This can be simply corrected by gently patting the cushions back into shape to redistribute the filling and reshape the covering.

Home Service Technicians

If you have a fault with your product, please contact our customer service team on 0333 777 8999.

If you have had the product for 28 days or less you may be offered a replacement, refund or for a fully trained home service technician to visit your home to assess the fault and repair the product where possible.

If you have had the product for more than 28 days we will send an independent home service technician to review and repair the product where possible and recommend further action.

You can write to us at

Home Customer Services
Next Retail Ltd.
Desford Road,
Leicester,
LE19 4AT

To view our full furniture range please visit
www.next.co.uk


Need Help?

With: Assembly instructions
Missing or damaged parts
CALL: 0333 777 8999

CROSBY STORAGE MODULAR SOFA

Assembly instructions

GETTING TO KNOW YOUR PRODUCT





CROSBY STORAGE MODULAR SOFA

Assembly instructions




GETTING TO KNOW YOUR PRODUCT

Components supplied. Please use this guide if you require replacement parts.




Footstool

Ref	Dimension	Visual	Qty
1	Footstool: H47.5xW77xD77CM		1
4	Seat cushion: 81x81x7CM		1



Centre piece

Ref	Dimension	Visual	Qty
2	Centre seat: H67xW95xD95CM		1
4	Seat cushion: 81x81x7CM		1
5	Back cushion of center 79x49x7CM		1

Corner piece

Ref	Dimension	Visual	Qty
3	Corner: H67xW95xD95CM		1
4	Seat cushion: 81x81x7CM		1
6	Back cushion of corner 81x49x7CM		2





Double Footstool

Ref	Dimension	Visual	Qty
7	Seat: H29.5xW154xD77CM		1
8	Back Cover: 154x81x7CM		1

CROSBY STORAGE MODULAR SOFA

Assembly instructions



1



CROSBY STORAGE MODULAR SOFA

Assembly instructions



2



CROSBY STORAGE MODULAR SOFA

Assembly instructions



3



CROSBY STORAGE MODULAR SOFA

Assembly instructions



4



CROSBY STORAGE MODULAR SOFA

Assembly instructions



5



CROSBY STORAGE MODULAR SOFA

Assembly instructions


6



CROSBY STORAGE MODULAR SOFA

Assembly instructions

7



NEXT

CROSBY STORAGE MODULAR SOFA

Assembly instructions

Actual product size

Corner piece: H86xW95xD95CM





Centre piece: H86xW95xD77CM

Footstool piece: H47.5xW77xD77CM

Double Footstool: H47.5xW155xD77CM

CAUTION: Maximum weight capacity of each seat is 130kg.

Pls remove the connectors if not in use otherwise its potential risk of hitting by foot.



NEXT

CROSBY STORAGE MODULAR SOFA

Assembly instructions

Actual product size

Corner piece: H86xW95xD95CM

Centre piece: H86xW95xD77CM

Footstool: H47.5xW77xD77CM

Double Footstool: H47.5xW154xD77CM

CAUTION: Maximum weight capacity of each seat is 130kg.

Pls remove the connectors if not in use otherwise its potential risk of hitting by foot.

